


## HOW TO START & USE YOUR GOLF CART

### Activate your Golf Cart with your badge and key

1. Locate the LED light on the dashboard.
2. Pass your card in front of the light.
3. If accepted, you'll hear a long beep.
4. Insert the key into the ignition.
5. Turn the key to the ON position.



### Using the Blinkers and Lights

Located on the bar behind the steering wheel.

**Important:** Blinkers do not auto-return. You must manually return them to the middle position after turning.

### Brake Types & Parking Brake

Depending on your golf cart, you may encounter the following brake types:

1. **Mechanical with Clamp Parking Brake:** Use the same clamp mechanism to release the parking brake.
2. **Mechanical with Safety Mechanism:** Simply push the accelerator to release the parking brake.
3. **Electric Brakes:** These brakes lock automatically when the flow of electricity stops, serving as a parking brake.



## FREQUENTLY ASKED QUESTIONS

### Charging Method (Electric Golf Carts) and indicators

Most electric golf carts come with a single charging cable. Some models may include 2-part charging cables. If it is the late, please consult with our staff for operation instructions. Remember to use proper charging outlets with the infrastructure for EV charging.

The electric gauge does not indicate charge level but reflects the power unit voltage.

### Customer Support Channels

Emergency Support Via WhatsApp: +506.8433.8601  
(08:00-21:00 Daily)

US Phone Number: +1.920.920.0071  
(08:00-17:00 Daily UTC-6).

**REMEMBER TO KEEP  
YOUR ELECTRIC  
GOLF CART  
CHARGED**

### Max Occupancy and Weight

Respect maximum occupancy: 4-Seater = 4 passengers max.  
6-Seater = 6 passengers max.

Overloading incurs a \$150 USD fine.

Max weight limits: 4-Seater = 362.48 kg. 6-Seater = 543 kg.  
Steep hills may reduce capacity to 25%.

### Gasoline Golf Cart

Are serviced by the company. Refueling standards apply and it is included in your rental fee. Just give us a call!



## STAY ON BOUNDARY

Our golf carts are equipped with advanced geofencing technology to ensure safe and convenient operation within designated areas. Each cart is programmed to function seamlessly within the boundaries of Tamarindo, Flamingo, Hacienda Pinilla, Potrero, Brasilito, Reserva Conchal, and Avellanas. Consult with our staff about the city limits and restricted areas.

